

**HAMMERLESS WREATH MACHINE**

# INSTALLATION INSTRUCTIONS

1. Jaw Assembly (1) will arrive fully assembled
2. Remove the clevis pin (A) at the bottom of the Jaw Assembly spring and place the single-hole end of one pedal linkage (11) between the Jaw Assembly Linkages.
3. Insert the clevis pin through both Jaw Assembly linkages and through the single Pedal Linkage hole
  - 3.1. Three sets of holes in the Jaw Assembly linkages are provided to adjust jaw opening at rest position
4. Re-insert the spring loop through the end of the clevis pin
5. Attach the Pedal Linkages (11) together with two  $\frac{1}{4}$  Bolts and Nuts (5 & 6)
  - 5.1. Adjust the Pedal Linkage attachment length per your mounting height
6. Attach the bottom of the Pedal Linkage to the Pedal (12) with one  $\frac{1}{4}$  Bolt and Nut (5 & 6)
7. Attach the Pedal to the Floor Mount (2) with  $\frac{3}{8}$  Bolt and Nut (7 & 8)
8. Mount the Jaw Assembly to the table with two countersunk holes (B)
9. Mount the Floor Mount to the floor or table through both holes (C)

PARTS LIST		
ITEM	QTY	DESCRIPTION
1	1	HAMMERLESS JAW ASSEMBLY
2	1	FLOOR MOUNT
5	3	1/4 BOLT
6	3	1/4 LOCK NUT
7	1	3/8 BOLT
8	1	3/8 LOCK NUT
11	1	PEDAL LINKAGE
11	1	PEDAL LINKAGE
12	1	PEDAL

